

Philips / Philetta 51
 1950-53; BC/LW/SW.



3. Emerson / 5781946; Broadcast band; electronically restored.



5. Westinghouse / H-125 "Little Jewel" 1945/47; Broadcast band; electronically restored.



7. Telefunken / Jubilate 205 1967/68; AM/FM/SW; electronically restored; has audio input.



2. Crosley / Fiver Deluxe Compact 1938; BC/SW.



4. RCA Victor / 9X561 1950; Broadcast band.



6. Crosley lot / Models 51, 50, and V 1923/24; Tuned RF (TRF) receivers.



8. Philco / 39-801939; Broadcast band.



Crosley / 58TC
 1948; Broadcast band.



11. Zenith / 6D0301946; Broadcast band; electronically restored; has bluetooth.



13. Stewart Warner / Jewel R-188?Circa 1935; Broadcast band; electronically restored.



15. Radiobell / 437 1936/1937; BC/LW.



10. Tonfunk / Violetta W125H1955/56; BC/LW/SW/FM; electronically restored; has audio in.



12. Grebe / MU1 Synchrophase 1925; Broadcast band.



14. RCA / 5T7 1936; BC/SW.



16. Phillips / B5X43A/741964/65;BC/LW/SW/FM Stereo; electronically restored; has bluetooth.



17. Silvertone / 132-818 1946; Broadcast band; chrome case.



Zenith / 4T26
 BC/SW.



21. Tradio / L-U61947; Broadcast band; coin operated hotel radio; has key.



23. Decotone / Model ? mid 1930s; Broadcast band; mirror clad case.



18. Truetone / D2418A1954; Broadcast band, clock radio; electronically restored; as audio in.



20. Stewart Warner / Magic Dial R-146A1936; BC/SW; Electronically restored; has audio in.



22. Radiola / III1924; Tuned RF (TRF) receiver; has power supply and C. Brandes headphones.



24. Atwater Kent / 361927; BC; has AK type Y power supply and Radiola UZ-325 speaker. Radio and power supply work.



25. Remler / 55651949; Broadcast band.



27. Arvin / 540T 1951; Broadcast band.



29. Zenith / 6S271936; BC/SW; electronically restored; has bluetooth.



31. Stewart Warner / 1231? 1933; Broadcast band.



26. Philco / 41-226 1941; BC/SW.



28. Radiola / 103 Speaker; has continuity.



30. Unknown / .1925; May be a Lemco.



32. Grebe / MU1 Synchrophase 1925; Broadcast band.

## **California Historical Radio Society**



33. Crosley / 11-105U

1951; Broadcast band; original condition; original color and paint.



35. Silver / Model ? Circa 1946; Broadcast band.



37. Heathkit / WA-1 Circa 1951; power supply and mono amplifier; tested, working.



39. Klipsch / Heresy Speaker pair; working.



34. Westinghouse / Aeriola Sr. Circa 1921; Tuned RF.



36. RCA / 128 1934/1935; BC/SW; electronically restored.



38. Westinghouse / WR212 1936/37; BC/SW.



40. Airline / 62-148 1934/35; Broadcast band.



41. Fada / 652 Temple1946; Broadcast band; has Catalin case.



43. Arvin / 540T 1951; Broadcast band.



45. Teeco / Model?

Mono amplifier; working.



47. Philips / 06Y28?
Circa late 1930s; Broadcast band.



42. Grundig / Model 87 Majestic USA
Circa 1959; AM/FM; electronically restored; has bluetooth.



44. Saba / FD18 1966/67; BC/LW/SW/FM Stereo.



46. Westinghouse / RC (RA and DA combined) 1921; Tuned RF; Broadcast band.



48. Unknown / .
Circa 1925; speaker with ship motif.



49. Elrey / Model ?
Circa 1933/34; Broadcast band; electronically restored.



50. Bendix / 55P3U 1949; Broadcast band.



51. Jackson Bell / 87 Tulip1931; Broadcast band; electronically restored.



52. Telefunken / Carabela 354 1944/1945; BC/SW; made in Spain.



53. Speaker / Model ?1920s case; modern speaker; has bluetooth.



54. Spartan / Equasonne 301 1929/30; Broadcast band.



55. Cossor / 71 1938; made in England; BC/SW/LW.



56. DeWald / A5021946; Broadcast band; has Catalin case.



57. Olympic / 6-5021946; Broadcast band.



59. Unknown / Model ?
Circa 1931; Small cathedral; Broadcast band.



61. Lorenz / Super 200 1937/38; BC/SW/LW.



63. Sonora / TNF-601939/40; Broadcast band; has 78 RPM phono; electronic restored, turntable works.



58. Arvin / 522A; chassis RE-76 1940/41; Broadcast band; electronically restored; has bluetooth.



60. Atwater Kent / 20 1924; Broadcast band; has tubes.



62. Stewart Warner / 01-5H7 1939; BC/SW.



64. McIntosh / MC30
Pair of mono amplifiers; working.



65. Philips / 208U 1943/44; BC/SW/LW.



67. Philips / Capella 735/4e/3d 1955/56; BC/LW/SW/FM; electronically restored; has audio in.



69. Philips / BD294 U 1949/50; BC/SW/LW.



71. Philips / Philetta B2D23A 1963/63; BC/SW/LW/FM.



66. DeWald / A501 1946; Broadcast band; has Catalin case.



68. General Electric / 1151954; Broadcast band; electronically restored; as audio in.



70. General Electric / S-22 Circa 1932; electronically restored.



72. E.H. Scott / Allwave 23 in Tasman cabinet 1934/35; BC/SW.



73. Philips / 209U-15 1946; BC/SW/LW.



75. ELAC / 10H Microcort
Turntable, 16/33/45/78 RPM; has 45 adapter and dust cover.



77. Zenith / TL405 Circa 1955; Broadcast band; AC or battery; electronically restored; has audio in.



79. Philco / 41-300X 1940/41; BC/SW.



74. Motorola / 66C Golden Voice
Circa 1956; BC, clock radio; electronically restored, onoff switch on rear panel; has audio in.



76. RCA / 77-DX
Circa 1950; Polydirectional microphone, directionality is switch selectable.



78. Silvertone / 47861937; BC/SW; electronically restored; has bluetooth.



80. Bang and Olufsen / Beogram 4004
Turntable, 33/45 RPM; has linear tracking; tested working.

# **Radio Day 2021 Auction**

Check frequently for updates

## California Historical Radio Society



81. McIntosh / 2300, C32, MR78
Includes 2300 power amplifier; C32 preamplifier; and MR78 tuner; has owners manuals; tested working.

11